

Контроллеры массового расхода газа

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

GAS MASS FLOW METER/CONTR



Gas mass flow controller



LCD display

The display of gas mass flow controller could display the instant flow, total flow, total time and control state. At the right of display there are any key to set the parameters.

The connection

The connection of gas flow meter :

1. Swagelok: DN3/6/10, 1/4" 3/8";
2. VCR connector: 1/4" 3/8" 1/8".





1

DISPLAY

Local LCD Display or none



2

Glad Hand

$\Phi 3, \Phi 6, \Phi 10, 1/8"$
 $1/4", 3/8"$



3

Power Supply

DC +15V/24V
flow meter < 400mA
flow controller < 600mA



4

Flow Range

F1 -0~10SCCM
F2 -10SCCM~30SLM
F3 -30SLM~150SLM
F4 -150~300SLM
F5 -300~1000SLM
F6 -1000~2000SLM
F7 -2000~7000SLM




5

Material of Base

316L Stainless steel



Item	The gas mass flow controller(gas flow meter)
Flow range	(0-5,10,20,30,50,100,200,300,500)SCCM;(0-1,2,3,5,10,20,30,50,100)SLM
Accuracy	1%FS of gas mass flow controller
Linearity	0.5%FS
Repeatability	0.2%FS of gas flow meter
Responding time	Less than 1s
Pressure difference	(0.0500 3)Mpa
Max Pressure	10MPa
Working temperature	5-65°C of gas mass flow controller
Input/output	Digital RS232/RS485
Power Supply	Analog: 0-5vdc or 4-20mA
Weight	7-16vdc, 1A of gas flow meter



The Top of the MFC

At the top of the MFC, there is a S connection.

The S connection with 8 hole.

1. output signal: red wire
2. zero :Violet wire
3. RS232 input signal : white wire
4. Voltage setting: yellow
5. rs232 output: orange
6. Current setting: brown
7. Valve control: blue
8. GND: green

The large flow controller

If your flow range is more than general, you may need this gas mass flow meter. The control valve is outside.



wireless Gas Flow Controller





Main Accessories: 1. DTU Module 2 Aerial 3. Power Adapter.

Other Accessories: Upload flowmeter and DTU information to the cloud platform.

(1) Use the SIM card of the Mobile Network if on Site Without wifi;

(2) WiFi is available on site abroad to browse data on Web pages.





По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93